

Benennung

Description

Bildtafel Nr.  
Plane of projection No.

A-Zu  
mod.  
state

FHG

Hydr.-Lenkung, Oberwagen

Hydr. steering, turntable

1 556 380

078

ETL-Nr.  
1 744 610


Blatt  
Sheet

1

Ersatzteilliste (Bildtafel)  
List of spare parts (Plane of project.)

ME = Mengeneinheit / QCD = Quantity Code  
 01 - Stück 06 - m<sup>3</sup> 17 - cm<sup>2</sup> 24 - Zoll  
 02 - kg 07 - l 18 - dm<sup>2</sup> 25 - mg  
 03 - t 08 - cm 20 - cm<sup>3</sup> 26 - 1/1000 Stück  
 04 - m 09 - g 22 - Satz  
 05 - m<sup>2</sup> 10 - mm 23 - Paar

Ä-Zust. mod.state	Pos. Item	Stücklisten-Nr. Liste of spare parts No.		Menge Quantity	ME QCD	Benennung	Description	Bemerkung Remark
		Teile-Nr. Part-No.	ETL					
	001	1683614		1.0	01	SERVOSTAT,ROSS-	ROSS-SERVOSTAT	
	017	1677876		1.0	01	LEITUNG,SCHLAUCH- 2SN_16NN3000P DIN 20066	HOSE ASSEMBLY	
	018	1201608		2.0	01	LEITUNG,SCHLAUCH- 2SN_12PP2800P DIN 20066	HOSE ASSEMBLY	
	020	1205193		1.0	01	LEITUNG,SCHLAUCH- 2SN_12PP3000P DIN 20066	HOSE ASSEMBLY	
*** ENDE DER LISTE ***						*** END OF THE LIST ***		

 <b>KRUPP</b> Ersatzteilliste List of spare parts (Plane of project)	Benennung		Description		Ersatzteilliste Nr. List of spare parts No.	Ä-Zu. mod. state	FHG
	LENKUNG, HYDR.- , OBERWAGEN		HYDR. STEERING, TURNTABLE		1744610-ETL		078
					Datum 13.03.86 Date	Seite Page	1

1 551 097 - 11.84