


CENTRE DECKING ASSY



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
1	6-679-991515	1	Panel Decking Assy LH Incl. Items 101-105	201	6-679-991511	1	Panel Centre RH
2	6-705-996863	1	Plate Tie	202	8738615	1	Grab Handle
3	6-869-990561	1	Support	203	7069201	2	Nut M8
4	6-679-991516	1	Panel Decking Assy RH Incl. Items 201-207	204	7066537	2	Washer M8
5	6-869-990562	1	Support	205	8356026	1	Edging x 60cm
6	6-869-990561	1	Support	206	8356026	1	Edging x 57cm
7	6-869-990502	1	Support Decking RH	207	6-392-990227	1	Door Assy Incl. Items 301 to 305
8	7069401	2	Nut M12	301	6-392-990226	1	Door Panel Access
9	7066539	2	Washer M12	302	8739257	2	Lock Budget
10	7050506	23	Screw Button Head M10 x 30mm	303	7045005	4	Screw M5 x 16 Long
11	7066538	23	Washer M10	304	7069004	4	Nut M5
12	7067212	23	Washer Spring M10	305	7066535	12	Washer M5
13	7069301	23	Nut M10				
14	7-885-000006	1	Plastioc Tape				
15	7-949-000561	4	Washer (Nylon)				
101	6-679-991513	1	Panel Centre LH				
102	8738615	1	Grab Handle				
103	7069201	2	Nut M8				
104	7066537	2	Washer M8				
105	8356026	1	Edging				