


JUNCTION BOX ASSEMBLY - CARRIER



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
1	6-176-990178	1	Box Junction	14	8735024	118	Female Terminal (Red)
2	6-184-991787	1	Bracket Elect. Control Box	15	8735025	4	Female Terminal (Blue)
3	6-184-991788	1	Bracket Electrical	16	460513	2	Seal Cab Base (Inside of Box Lid) 30cm
4 +	6-978-990600	1	Elect Assy Relay Panel	17	7-296-000004	2	Inhibitor Corrosion
5	7-364-001510	4	Connector Strain Relief				
6	7-659-000042	4	Locknut 1/2"				
7	7-364-001703	1	Strain Relief Connector				
8	7-659-000262	1	Locknut Electrical				
9	7045103	4	Screw M6 x 25 Long				+ See further breakdown in this group
10	7066536	16	Washer Plain M6				
11	7067214	4	Washer Spring M6				
12	7069102	8	Nut M6				
13	8735319	6	Eyelet 2BA				

6-978-990626
Issue No. 01