


ELECT ASSY EMERGENCY GEAR SWITCH



| NO. | PART NO.     | QTY. | DESCRIPTION                            | NO. | PART NO. | QTY. | DESCRIPTION |
|-----|--------------|------|--|-----|----------|------|-------------|
| 1 + | 6-512-990259 | 1    | Harness Assy Emergency Gear Switch     |     |          |      |             |
| 2   | 7-589-990077 | 1    | Lens Insert Emergency Manual Gearshift |     |          |      |             |
| 3   | 7-638-990043 | 1    | Mounting Panel Switches 3 Way          |     |          |      |             |
| 4   | 7-872-990235 | 1    | Switch Safety                          |     |          |      |             |
| 5   | 7-589-990109 | 1    | Lens Insert Forward/Reverse            |     |          |      |             |
| 6   | 8387664      | 1    | Plug Blanking Rocker Switches          |     |          |      |             |
| 7   | 7-872-990275 | 1    | Switch Rocker 3 Position               |     |          |      |             |

+ See further breakdown in this group

6-978-990629  
Issue No. 00