


VALVE SUPPLY DUMP



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
-	7-926-990445	1	Complete Assembly	14	9-926-990191	1	Lower Body
*	9-926-107798	1	Service Kit	15	9-926-990186	2	Screw
1	8775960	4	Sems Unit	16	9-926-990187	2	Lockwasher
2	9-926-107793	1	Cover	17*	-	1	Exhaust Check
3 *	-	1	'O' Ring	18	9-926-101305	1	Exhaust Cover
4	9-926-107794	1	Service Chamber Spring	19	9-926-101286	1	Inlet & Exhaust Valve Assy Incl. Items 21,24,26
5	9-926-107795	1	Piston	20*	-	1	Retaining Ring
6 *	-	2	'O' Ring	21	9-926-101290	1	Valve Guide
7 *	-	2	A.E. Ring	22*	-	1	'O' Ring
8 *	-	2	Circlip	23*	-	1	'O' Ring
9 *	-	3	'O' Ring	24	9-926-101292	1	Valve Spring
10	9-926-107796	1	Piston Stem & Exhaust Seat	25*	-	1	Inlet & Exhaust Val
11	9-926-990178	4	Sems Unit	26	9-926-101293	1	Valve Retainer
12	9-926-107797	1	Spring Housing	27*	-	1	Filter
13*	-	1	Sealing Ring				

7-926-990445
Issue No. 00