


# HEATER ASSEMBLY - DIESEL

# GROVE

## EXHAUST PARTS




NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
2	9-515-100411	1	NIPPLE				
3	9-515-100412	1	ELBOW				
4	9-515-100413	1	SHIELD				
5	9-515-100285	A/R	STUD				

A/R = AS REQUIRED

# HEATER ASSEMBLY - DIESEL

GROVE

## CASE AND HEAT EXCHANGER PARTS




NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
	* 9-515-100415		EXHAUST SEAL KIT	17	9-515-100729	1	EXCHANGER, HEAT
	□ 9-515-100683		SUB-ASSY-HEAT EXCHANGER + THERMOSTAT	18	9-515-100180	1	GROMMET
1	9-515-100418	1	BAR	19	7-950-100350	1	LOCKWASHER 10 REG
2	9-515-100419	1	COVER	20	7-660-101100	A/R	NUT, HEX
3	□	1	CLAMP	21	9-515-100692	1	PLATE, COVER
4	□ 9-515-100421	1	THERMOSTAT	22	9-515-100693	1	CONNECTOR, TERMINAL
5	□	1	COVER, TOP				
6		1	BRACKET, IGNITER MTC				
7	9-515-100684	1	BRACKET				
8	9-515-100685	1	TUBE, AIR				
9		1	SPACER				
10	9-515-100686	1	CASE ASSY INCLUDES NBR 6, 9, + 19				
11	9-515-100687	2	DEFLECTOR, AIR				
12	* 9-515-100295	1	WASHER				
13	* 9-515-100688	1	GASKET, EXHAUST				
14	* 9-515-100689	1	CONNECTOR, EXHAUST				
15	□ 9-515-100690	1	BRACKET				
16	□ 9-515-100180	1	GROMMET				

\* REPAIR KIT AND/OR PART OF KIT  
 □ SECOND REPAIR KIT AND/OR PART OF 2ND KIT  
 A/R = AS REQUIRED

HEATER ASSEMBLY - DIESEL  
 FUEL AND IGNITION SYSTEMS

GROVE




NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
1	9-515-100427	1	PACK, IGNITION				
2	9-515-100341	1	GASKET				
3	9-515-100428	1	BURNER HEAD				
4	9-515-100429	1	PAD				
5	9-515-100430	1	SCREW				
6	9-515-100431	1	PLUG				
7	9-515-100695	1	CARBURETOR SEE FURTHER BREAKDOWN IN THIS PARTS LIST				
8	9-515-100433	1	FUEL LINE				
9	9-515-100217	1	CONNECTOR				
10	9-515-100348	1	IGNITER ASSY				
11	9-515-100216	1	NUT				

# HEATER ASSEMBLY - DIESEL

# GROVE

## CONTROL PANEL PARTS




NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
	* 9-515-100696		KIT-THERMO CONTROL	15	9-515-100501	1	LIGHT-RED
	- 9-515-100437		SWITCH KIT	16	9-515-100405	1	LEVER
	9-515-100509		AUTO CONTROL PANEL ASSY	17		1	NUT
			INCLUDES NBR 8-15, 17,	18		1	LOCKWASHER
			18 + HARNESS	20	9-515-100706	1	ARM, PIVOT
1 *		1	ROD	21	9-515-100707	1	NUT, STOP
2 *		2	SETScrew	22 *		1	SWITCH
3 *		1	STOP	23 *		1	INSULATOR
4 *	9-515-100264	1	BLADE	24	9-515-100708	1	SHIELD, HEAT
5 *		1	BRACKET	25	7-340-000001	2	CAPACITOR
6	9-515-100697	1	SPACER, HEX				
7	9-515-100698	1	SWITCH, FLAME				
8	9-515-100365	1	SWITCH				
9	9-515-100439	1	SWITCH				
10	9-515-100700	1	PLATE				
11	7-111-060310	1	SCREW				
			6-32 NC X 3/8" - GRD 1				
12	9-515-100502	1	LIGHT-GREEN				
13	9-515-100367	1	FUSE, 30 AMP				
14	9-515-100251	1	HOLDER, FUSE				

\* REPAIR KIT AND/OR PART OF KIT  
 - THIRD REPAIR KIT AND/OR PART OF 3RD KIT

# HEATER ASSEMBLY - DIESEL

GROVE

## CIRCUIT BOARD PARTS




NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
1	9-515-100709	1	BOARD, CIRCUIT				
2	7-111-060610	3	SCREW, MACH #6-32NC X 3/4" - GRD 1				
3	7-950-060050	3	LOCKWASHER #6 REG				
4	9-515-100303	1	SWITCH				

# HEATER ASSEMBLY - DIESEL

GROVE

## CARBURETOR PARTS




NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
	9-515-100695		COMPLETE ASSY	17	E	1	ORIFICE
	* 9-515-100443		FUEL BOWL KIT	18	9-515-100712	1	SOLENOID
	E 9-515-100445		CARBURETOR KIT	19	NOT SERVICED	1	LABEL
	- 9-515-100444		JET KIT	20	*	1	PLUG
1	*	1	FITTING	21	*	1	BOWL
2	NOT SERVICED	1	TUBING	22	*E	1	GASKET
3	*	1	SCREW	23	*E	1	PIN
4	*	1	LOCKWASHER	24	*	1	COVER
5	*E	1	NEEDLE + SEAT	25	*E	1	SCREEN
6	*E	1	FLOAT	26	NOT SERVICED	1	THERMOSTAT
7	NOT SERVICED	1	BRACKET	27	NOT SERVICED	1	WASHER
8	-	1	JET	28	NOT SERVICED	1	SCREW
9	-	1	MIXER				
10	-	1	O RING				
11	NOT SERVICED	1	GASKET				
12	9-515-100711	1	SOLENOID				
13	NOT SERVICED	1	BODY				
14	NOT SERVICED	1	HEATER				
15	E	1	NEEDLE				
16	E	1	O RING				

\* REPAIR KIT AND/OR PART OF KIT  
 E SECOND REPAIR KIT AND/OR PART OF 2ND KIT  
 - THIRD REPAIR KIT AND/OR PART OF 3RD KIT

# HEATER ASSEMBLY - DIESEL

GROVE

## MOTOR AND BLOWER PARTS




NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
*	9-515-100713		BLOWER, COMBUSTION	16	*	1	CLAMP
□	9-515-100714		SUB. ASSY. MOTOR+BLOWER HOUSING	17	*	1	COVER
-	9-515-100703		KIT, -AIR HOSE + CLAMP	18	*	1	WHEEL ASSY
+	9-515-100715		KIT-HOSE CLAMP	19	*	1	SPACER
1	*	1	PLATE, MTG	20	-	1	HOSE
2	*	4	NUT	21	+	2	CLAMP
3	*	4	SCREW	22	-	1	ELBOW
4	*	6	WASHER	23	-	1	DUCT
5	*	1	MOUNT, MOTOR	24	+	2	CLAMP
6	*	1	SCREW	25	+	1	SCREW
7	*	1	WASHER	26	+	1	WASHER
8	*□9-515-100458	1	MOTOR				
9	*	1	GASKET				
10	*	2	WASHER				
11	*	2	NUT				
12	*	2	WASHER				
13	*	1	HOUSING				
14	*	2	WHEEL				
15	* 9-515-100716	1	PROPELLER				

\* REPAIR KIT AND/OR PART OF KIT  
 □ SECOND REPAIR KIT AND/OR PART OF 2ND KIT  
 - THIRD REPAIR KIT AND/OR PART OF 3RD KIT  
 +

# HEATER ASSEMBLY - DIESEL

# GROVE

## REMOTE CONTROL PARTS



NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
1	9-515-100717	1	HARNESS, CONTROL				
2	9-515-100407	1	PANEL				