


VALVE ASSEMBLY - STEERING

GROVE



NO.	PART NO.	QTY	DESCRIPTION	NO.	PART NO.	QTY	DESCRIPTION
	7-926-001867		COMPLETE ASSY	17	NOT SERVICED	1	SLEEVE, CONTROL
	* 9-926-102438		REPAIR KIT	18	NOT SERVICED	1	SPOOL, CONTROL
1 *	9-632-100002	1	SEAL, OIL	19	9-926-100089	6	SPRING
2	9-926-102423	1	RING, RETAINING	20	9-926-100088	1	PIN
3	9-926-102424	1	BUSHING	21 *	7-755-040000	3	SEAL
4 *	9-926-102425	1	SEAL	22	9-926-102432	1	PLATE
5 *	9-632-100005	1	RING, QUAD	23	9-926-100319	1	DRIVE
6	9-926-102426	1	NEEDLE BEARING KIT INCLUDES nbr 7 + 8	24	9-926-102445	1	GEROTOR
7	NOT SERVICED	2	RACE, BEARING	25	9-926-102173	1	SPACER (.865)
8	NOT SERVICED	1	BEARING, NEEDLE THRUST	26	9-926-102435	1	CAP, END
9	9-926-102427	1	SETSCREW	27	9-632-100142	7	SCREW
10 *	7-755-012000	1	O-RING				
11	9-926-102428	1	SEAT				
12 *	7-755-011000	1	O-RING				
13	9-926-102429	1	BALL				
14	9-926-102430	1	RETAINER				
15	9-926-102444	1	PARTS ASSY, CONTROL INCLUDES nbr 16-20				
16	NOT SERVICED	1	HOUSING				

* REPAIR KIT AND/OR PART OF KIT