



Manitowoc Cranes



For Reference Only
See Cab Installation
For Callout



CONNECTOR LOADING
 CAVITY 1 - HI SPEED
 CAVITY 2 - LO SPEED
 CAVITY 3 - PARK
 CAVITY 4 - SWITCH
 CAVITY 5 - SEAL PLUG
 CAVITY 6 - GROUND (MOTOR CASE)