TO ALTERNATOR POSITIVE (+)
100 RED CABLE
(SEE DETAIL C)

GRID HEATER RELAY TO FUSE 1/0 RED CABLE

TO STARTER POSITIVE (+) STUD #4 RED CABLE (SEE DETAIL B)

6

Ö Ö

GRID HEATER CONNECTION REF

8 TO STARTER
10 RED CABLE
(SEE DETAIL B)

TO STARTER
SOLENOID POSITIVE (+)
#4 RED CABLE
(SEE DETAIL B)

DETAIL H FUSE AND RELAY PANEL

ROUTE TO ENGINE HARNESS

DIODE BLOCK

J1939 CONNECTION

(SHEET 4 QF 4

Page 857

80027615