


ELECTRICAL ASSEMBLY ENGINE



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
1	6-512-990260	1	Harness Assy Engine - Cummins	8	6-246-990128	1	Lead Starter Neg to Earth Starter to Chassis
2	8411113	1	Nameplate Overload Circuit Breaker				
3	8788791	1	Circuit Breaker Miniature 50 Amp				
4	8788792	1	Cover Splash Proof Clear for MCB				
5	6-246-990059	1	Lead Starter Neg to Earth - Master Switch to Chassis				
6	6-246-990127	1	Lead Battery Pos to M10 4700 Lg - Battery Pos. to Starter				
7	6-246-990110	1	Lead Battery Neg to M10 3400 Lg - Battery Neg to Master Switch				

6-978-990633  
Issue No. 00