


FLOW INDICATOR VALVE



NO.	PART NO.	QTY.	DESCRIPTION	NO.	PART NO.	QTY.	DESCRIPTION
-	7-872-990182	1	Valve Flow Indicator Complete				
1	9-926-990903	1	Socket				
2	9-926-990904	1	Spring				
3	9-926-990905	1	Washer				
4	8781241	1	Ball				
5	9-926-990906	1	Valve Housing				
8	9-926-990907	1	Bush				
51	9-926-990908	1	Flow Indicator Sub Assembly (Includes Items 45 to 50)				
50	9-926-990909	1	Cap Protection				

‡ Component parts not available separately